

syncromesh

4 INPUT
SWITCH PUCK

5
YEAR
PRODUCT
WARRANTY

IP
20
INGRESS
PROTECTION



CSP-4C-M
LEARN MORE

Please ensure that the luminaire is installed in accordance with the below instructions. **Teknik Lighting Solutions Pty Ltd** assumes no responsibility for inappropriate use or installation of the product, including any associated damage caused.

1. **Electrical Safety:** Not a DIY product. Ensure the fitting is installed by a qualified electrician in compliance with relevant Australian Standards (AS3000) and local regulations (where applicable). Always turn off the power supply before installation, maintenance, or cleaning.

2. **Compatibility:** Verify that the fitting is compatible with the existing power supply, mounting structure and dimmer systems, if applicable. Using incompatible equipment may result in damage or reduced performance.

3. **Damage Check:** Inspect for damage before installation. Do not use fittings with visible damage to wires, housing, or components.

4. **Avoid Modifications:** This product is intended for use in accordance with its specifications and installation guidelines. Any use outside these parameters is at the user's risk. Do not alter or tamper with the fitting. Unauthorised modifications can compromise safety and void the warranty.


5. **Switch Cycles:** Good design practice does not encourage 24/7 continuous operation of lighting products without a routine switching or regulatory test cycle. For extended use, limit operation to 12 hours per day for industrial/commercial applications and 6 hours per day for residential applications.

6. **Disposal:** Dispose of fittings responsibly in accordance with local recycling and disposal regulations. LEDs contain electronic components that may require special handling.

7. **Liability Limitation:** TEKNIK shall not be held liable for incidental, indirect, or consequential damages resulting from the use or inability to use this product.

8. **Intellectual Property:** This product utilises intellectual property in the form of registered designs, trademarks, and/or patents. Such intellectual property remains the property of Teknik Lighting Solutions Pty Ltd in all cases.

DIMENSIONAL DRAWING



WIRING


- L

Terminal for live lead input
- N

Terminal for neutral lead input
- K1-K4

Terminals for push buttons
- COM

Common terminal for grounding to the push buttons connected to the coupler



PUSH BUTTON CONFIGURATION

1. Power the puck and use the BaseBuild app on an Apple iPad (via the Syncromesh Air Connector) to discover and onboard the device to your Syncromesh network.

2. In BaseBuild, locate the puck and configure its button functions. Each button can be assigned to control a luminaire, a group, or a scene.

For advanced button behaviour such as scene sequencing or time-based rules, additional configuration is available via the Fitout local web interface or Portfolio cloud platform.